


audeo™



ESCAPE **SPORT II**

ACTIVE SOUND

OPEN-EAR EARBUDS


QUICK START + INSTRUCTION GUIDE

ITEM: AOESCAPEII

CONTROLS

1 TOUCH



Play or Pause




Answer or End Call

2 TOUCH



Track Back
Left Earbud




Track Forward
Right Earbud

3 TOUCH



Volume Low
Left Earbud





Volume High
Right Earbud

1 TOUCH & 1.5 SECONDS HOLD


Reject Call




2 SECONDS HOLD




Voice Assistant

1 TOUCH & 5 SECONDS HOLD


Turn Off/On Earbuds



Basic Functions

Indicates if the earphones are on/off, pairing, or charging.

1 EARPHONE STATUS LIGHT

Indicates if the earphones are on/off, pairing, or charging.

2 MULTI-FUNCTION BUTTON




- Touch and hold the button for 5 seconds to turn ON/OFF your earphones.
- When there is an incoming call, touch the button on the RIGHT or LEFT earphone once to answer the call, touch the button once again to hang up the call.
- When there is an incoming call, touch and hold the button on the RIGHT or LEFT earphone for 1.5 seconds to reject the call.
- When playing music, touch the button on the LEFT or RIGHT earphone once to pause music, touch the button once again to play music.
- When playing music, double touch the button on the RIGHT earphone to skip to the next track, double touch the button on the LEFT earphone to skip to the previous track.
- When playing music, triple touch the button on the RIGHT earphone to increase the volume, triple touch the button on the LEFT earphone to decrease the volume.
- Hold the button on either the LEFT or RIGHT earphone for 2 seconds until you hear the "beep" prompt to activate your phones Voice Assistant.

3 LED INDICATOR LIGHT

The light will flash WHITE when being charged, and the WHITE light will remain on when full charged.

4 TYPE-C CHARGING PORT



This is the area to plug-in and charge your charging case. If the earphones are in the charging case they will charge first.




Operation Instructions

CHARGING YOUR EARBUDS

- 1 Connect the Type-C cable (only use the provided cable) to a computer USB port or a USB wall charger (not included). Plug the other end of the Type-C cable into the TYPE-C CHARGING PORT (4) located on the back side of the charging case station.




- 2 Open the top of the charging case and place your earphones in their designated areas. Once properly in place the LED lights (1) on the earphones will illuminate ORANGE. When the earphones are fully charged the ORANGE LED light will automatically turn off.




TURNING YOUR EARBUDS ON / OFF

- 1 Touch and hold the Multi-Function button (2) for 5 seconds to turn the earphones on or off
- 2 Alternatively, when you remove your earphones from the charging case station they will turn ON automatically. When you put them back in the charging case station they will turn OFF automatically and begin to charge if needed.



BLUETOOTH PAIRING

- 1 Hold the Multi-Function button (2) for 5 seconds to turn on and enter pairing mode—the LED light (1) will flash WHITE & ORANGE. You can also pick up both earphones from the charging case station your earphones will automatically enter pairing mode.
- 2 Enable Bluetooth on your device and select “audeo Escape2”. Once connected, the LEDs turn off and you’ll hear “Bluetooth Connected.”



SPECIFICATIONS

Bluetooth Version	6.0
Transmission Range	10 m
Driver Unit	14.2 mm
Earphone Batteries	3.7V 50mAh Li-Po rechargeable (Each)
Charging Case Battery	3.7V 400mAh Li-Po rechargeable
Play Time	6-7 hours
Charging Case Supply Power For Earphones	Up to 25 hours
Earphone Charging Time	About 1.5 hours
Charging Case Charge Time	About 2 hours
Input (USB-C)	5V $\overline{\text{---}}$ 320mA

SAFETY INSTRUCTIONS

- The battery shall not be exposed to excessive heat such as sunshine.
- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by audeeo Innovations LTD is under license. Other trademarks and trade names are those of their respective owners.





This appliance should not be put into the domestic garbage at the end of its useful life, but must be disposed of at a central point for recycling of electric and electronic domestic appliances.



This symbol on appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.



To prevent possible hearing damage, do not listen at high volume levels for long periods. For your own safety, please be aware of your surroundings when using these earphones. Take caution in regards to inserting objects into ear canal, use at own risk. Not suitable for children.



The power delivered by the charger must be between min 0.06 Watts required by the radio equipment, and max 1.6 Watts in order to achieve the maximum charging speed.

Simplified eu declaration of conformity hereby, Audeeo Innovations LTD. Declares that the radio equipment type model AOESCAPEII is in compliance with directive 2014/53/EU. The full text of the eu declaration of conformity is available at the following internet address: audeeo.eu/pages/eu-declaration-of-conformity

Manufactured & Distributed by:

Audeeo Innovations LTD., Chancellors House, 3 Brampton Lane, London, NW4 4AB, UK.

Audeeo Innovations LTD., 77 Camden Street Lower, Dublin, D02 XE80, Ireland.

audeeo™ is a registered trademark of Audeeo Innovations LTD.

Grundläggande funktioner

Visar om hörlurarna är på/av, i parkopplingsläge eller laddas.

SV

1 STATUSINDIKATOR FÖR HÖRLURAR

- Indikerar om hörlurarna är i parkopplingsläge.

2 MULTIFUNKTIONSKNAPP




- Tryck och håll knappen i 5 sekunder för att slå PÅ/AV dina öronsnäckor.
- När ett samtal kommer in, tryck på knappen på HÖGER eller VÄNSTER öronsnäcka en gång för att svara på samtalet, tryck på knappen en gång till för att lägga på samtalet.
- När ett samtal kommer in, tryck och håll knappen på HÖGER eller VÄNSTER öronsnäcka i 1,5 sekunder för att avvisa samtalet.
- När du spelar musik, tryck på knappen på VÄNSTER eller HÖGER öronsnäcka en gång för att pausa musiken, tryck på knappen en gång till för att spela musiken.
- När du spelar musik, dubbeltryck på knappen på HÖGER öronsnäcka för att hoppa till nästa låt, dubbeltryck på knappen på VÄNSTER öronsnäcka för att hoppa till föregående låt.
- När du spelar musik, trippeltryck på knappen på HÖGER öronsnäcka för att höja volymen, trippeltryck på knappen på VÄNSTER öronsnäcka för att sänka volymen.
- Håll knappen på antingen VÄNSTER eller HÖGER öronsnäcka i 2 sekunder tills du hör en "beep"-signal för att aktivera din telefons röstassistent.

3 LED-INDIKATORLJUS

Lampan blinkar VIT när den laddas, och det VIT ljuset kommer att vara på när batteriet är helt laddat.

4 TYPE-C LADDAREPORT



Detta är platsen där du ansluter laddningskabeln för att ladda laddningsfodralet. Om hörlurarna ligger i laddningsfodralet kommer de att laddas först.




Instruktioner

LADDA DINA HÖRLURAR

- 1 Anslut typ-C-kabeln (använd endast den medföljande kabeln) till en USB-port på datorn eller en USB-laddare (medföljer ej). Anslut den andra änden av Type-C-kabeln till TYPE-C-LADDAREPORTEN (4) på baksidan av laddningsstationen.




- 2 Öppna laddningsfodralet och placera öronsnäckorna i facken. När det är korrekt anslutet kommer LED-lamporna (1) på hörlurarna att lysa i ORANGE. När hörlurarna är helt laddade kommer den ORANGE LED-lampan att stängas av automatiskt.




SLÅ PÅ/AV HÖRLURARNA

- 1 För att slå på eller av hörlurarna, tryck och håll ner multifunktionsknappen (2) i 5 sekunder.
- 2 Alternativt, när du tar bort hörlurarna från laddningsstationen, slås de på automatiskt. När du lägger tillbaka dem i laddningsstationen, stängs de av automatiskt och börjar ladda om det behövs.



BLUETOOTH-PARNING

- 1 Håll in multifunktionsknappen (2) i 5 sekunder för att slå på och gå in i parkopplingsläge — LED-lampan (1) blinkar i VITT och ORANGE. Du kan också ta ut båda hörlurarna från laddningsstationen så att de automatiskt går in i parkopplingsläge.
- 2 Aktivera Bluetooth på din enhet och välj "audeeo Escape2". När den är ansluten släcks lamporna, och du hör "Ansluten via Bluetooth".



SÄRDRAG

Bluetooth-version	6.0
Sändande port	10 meter
Styrenhet	14,2 millimeter
Hörlursbatterier	3,7V 50mAh Li-Po rechargeable (Each)
Batteriladdningsfodral	3,7V 400mAh Li-Po rechargeable
Fritidsaktiviteter	6-7 timmar
Strömförsörjning för laddningsfodralet För hörlurar	Upp till 25 timmar
Laddningstid för hörlurar	Ungefär 1,30
Laddningstid för laddningsfodralet	Cirka 2 timmar
Tulo (USB-C)	5V $\overline{\text{---}}$ 320mA

SÄKERHETSINSTRUKTIONER

- Utsätt inte batteriet för extrema temperaturer, såsom solljus.
- Använd inte den här enheten nära vatten.
- Rengör endast med en torr trasa.
- Täck inte över ventilationsöppningarna. Installera enheten enligt tillverkarens anvisningar.
- Installera inte nära värmekällor som element, värmespjäll, spisar eller andra apparater (inklusive förstärkare) som producerar värme.
- Skydda nätsladden från att trampas på eller klämmas, särskilt vid kontakter, uttag och där de kommer ut ur apparaten.
- Använd endast tillbehör som rekommenderas av tillverkaren.
- Koppla ur enheten från vägguttaget under åskväder eller om den inte används under en längre tid.



Bluetooth®-ordmärket och logotyperna är registrerade varumärken som ägs av Bluetooth SIG, Inc. och all användning av sådana varumärken av audeeo Innovations LTD sker under licens. Andra varumärken och handelsnamn tillhör sina respektive ägare.




När apparaten är uttjänt får den inte slängas med hushållsavfallet, utan måste lämnas till en central återvinningsstation för elektrisk och elektronisk utrustning.



Denna symbol, som finns på enheten, användarmanualen och förpackningen, påminner dig om detta viktiga faktum. Materialen som används i den här enheten är återvinningsbara. Genom att återvinna din gamla enhet bidrar du aktivt till att skydda miljön. För mer information om insamlingsplatser, vänligen kontakta dina lokala myndigheter.



För att förhindra hörselskador, undvik att lyssna på musik på hög volym under längre perioder. För din säkerhet, var uppmärksam på din omgivning när du använder hörlurar. Var försiktig så att du inte för in främmande föremål i hörselgången. Användning på egen risk. Ej lämplig för barn.



Den effekt som levereras av laddaren måste ligga mellan minst 0,06 watt och maximalt 1,6 watt, vilket krävs för att ladda radioutrustningen i högsta laddningshastighet.

Förenklad EU-försäkran om överensstämmelse: Audeeo Innovations LTD. försäkrar att radioutrustningsmodellen AOESCAPEII överensstämmer med direktiv 2014/53/EU. Den fullständiga texten i EU-försäkran om överensstämmelse finns tillgänglig på följande internetadress: audeeo.eu/pages/eu-declaration-of-conformity

Producerad och distribuerad av:

Audeeo Innovations LTD., Chancellors House, 3 Brampton Lane, London, NW4 4AB, Storbritannien.

Audeeo Innovations LTD., 77 Camden Street Lower, Dublin, D02 XE80, Irland.

audeeo™ är ett registrerat varumärke som tillhör Audeeo Innovations LTD.