



SAFETY PRECAUTIONS

- Read all the instructions carefully before using.
- Check that the voltage marked on the rating label matches your mains voltage.
- The speaker should not be taken apart or modified.
- Do not place the speaker in constant sunlight or near naked flames such as wood stoves, lit candles, etc.
- Never subject the speaker to high temperatures, damp or dusty environments, heavy vibration, or impacts.
- Protect your hearing. Listening on high volume for prolonged periods can lead to permanent hearing loss.
- The speaker must only be repaired by qualified service technicians.
- This speaker is splash proof. Do not submerge under water, doing so will result in permanent damage.
- Do not expose the speaker to water while charging.

SPECIFICATION

Input: DC5V/1A

Speaker output: 5W

Driver: 1 x 2.5"


Battery: 2200mAh

Material: plastic, PU leather handle

Bluetooth Operating frequency: 2402-2480MHz


1: Power on/off

2: USB charge port



3: USB player

4: AUX Port



Accessories

1 x Bluetooth speaker, 1 x Micro USB-cable, 1x remote control, 1 x User manual

Compatibility

This product is compatible with Bluetooth enabled mobile phones and devices.

Charge

1. Connect speaker with PC/Laptop/Mac or any 5V USB adapter (not included) by the USB cable included.
2. Red LED turns ON during charging, turns OFF after fully charged.
3. Unplug USB cable after fully charged.
4. Red LED twinkles when low power (<21%), with a warning sound.

Turning ON/OFF

Hold the power button for approx. 2 seconds to turn on, you would hear a starting chime.

Hold it again for approx. 2 seconds to turn off.

Pairing

1. Turn on the speaker to be ready for pairing. After 3-4 seconds, you would hear a chimed Bluetooth sound.
2. Activate the Bluetooth function on your mobile phone or any Bluetooth devices, search the speaker and select the name "GlowSound1", and connect the speaker with the device via Bluetooth pairing
3. The Bluetooth sound is chimed once more after paired.

Note:

1. Keep the range of 1 meter when pairing. If the pairing was not successful, turn off the speaker and re-pair again.
2. After successful pairing, paired devices will remember each other so there is no need to pair again unless pairing information is deleted.
3. To pair with a new device, follow steps 1-3 above after disconnected from existing device.













TWS (True Wireless Stereo) Function: to pair one mobile phone with 2 speakers together

1. Make sure you have 2 GlowSound1 speakers at your hand, turn on both speakers together, then quickly double click "Power" buttons of both speakers, both speakers will into pairing mode to pair with each other first.
2. Wait for around 5-10 seconds until two speakers "beep" once in sequence, which means both speakers paired with each other already.
3. Then, activate Bluetooth function of your device and pair with Bluetooth name GlowSound1. You would enjoy music in True Wireless Stereo sound from two speakers simultaneously.

Warm notes:

1. You can only enjoy TWS function when you have 2 ES652800 speakers.
2. If you want to disconnect existing TWS connection, double click "Power" button of either speaker, the sub-speaker will disconnect, the host speaker will keep playing music.
3. If you want to establish TWS connection with 2nd speaker after your device connected with one speaker already, please long press "power" button to disconnect from your existing paired device, then follow above steps 1-3.

Operation by remote control (please remove the plastic tab from the battery cover before use).

-  1. Standby: press to into/out of Standby mode after powering on the speaker.
-  2. Change brightness.
-  3. Switch on/off the light.
-  4. Switch to Bluetooth mode.
-  5. Go to selected single color directly.
-  6. Repeatedly press it to change colors in a loop.
-  7. Switch light to Flash mode (Beats to music).
-  8. Switch light to Smooth mode (Breathing light slowly change colors)
-  9. Switch to white color directly.
-  10. Go to previous/next track (not workable under AUX mode).
-  13. Play and Pause.
-  14. Voice - and +
15. Switch to AUX or USB-play mode.



Notes:

1. Above operations and sequence based on factory default setting.
2. Speaker memorizes previous lighting status before turn-off, when you turn it on again, it will display the same lighting mode/color/brightness.

Warm notes 2:

3. Above operations and sequence based on factory default setting.
4. Speaker memorizes previous lighting status before turn-off, when you turn it on again, it will display the same lighting mode/color/brightness.

AUX connection

1. Connect the AUX cable (not included) to the AUX jack.
2. Insert the other end of the cable into the headphone or LINEOUT jack of the external device.



Waste electrical products should not be disposed of with household waste. All electronic products with the WEEE logo must be collected and sent to approved operators for safe disposal or recycling. Please recycle where facilities exist. Many electrical/electronic equipment retailers facilitate "Distributor Take-Back scheme" of household WEEE. Check with your Local Authority or retailers for Designated Collection Facilities (DCF) where consumers may dispose of their WEEE free of charge."



To avoid possible hearing damage, do not listen at high audio volume for long periods of time.